

CRUISE CONTROL

Cruise Control operation and repair procedures are identical to those covered in Section 6F of the 1967 Pontiac Service Manual. Installation of com-

ponent parts in Firebird, including switches and wiring, are shown in figures 6F-1 and 6F-2 below.




Fig. 6F-1 Cruise Control Installation

